




Koganei Clean System products provide complete support for the maintenance of a clean environment inside the cleanroom.

Koganei Clean System products meet the needs of the ultra-clean production environment. In everything from actuators and valves to air preparation and auxiliary equipment, anti-corrosion materials processing and other Koganei-developed design concepts serve to prevent particle contamination within the cleanroom. These perfectly designed mechanisms, which resolve even the slightest leaks to the outside during operations, have already won a high level of reliability.

Koganei Cleanliness

There is currently no standard in JIS or elsewhere for methods of evaluating cleanliness for pneumatic equipment in the cleanroom specifications. Therefore, to measure the effects of cleanroom contamination by pneumatic equipment, Koganei has decided to use “number of particles generated per 10 operations,” rather than particle density. Koganei has also developed classifications for application classes in cleanroom, based on JIS and other upper limit density tables, and on the company’s own experience.



- Remarks:
1. In the above table, product performance in terms of the number of particles generated per 10 operations is expressed as the upper limit of particles corresponding to the equivalent JIS or ISO class.
 2. In the above table, values in the JIS, ISO, and FED-STD upper limit density tables are calculated as upper density per liter.
 3. The classes shown are clean levels as classified in JIS and ISO.

From the above definitions, the Koganei clean level classes can be viewed as the level of average contamination per liter of surrounding air over a period of 10 operations in cleanroom. Air ventilation in cleanrooms is usually faster than 1 cycle per minute, and clean volumetric capacity is usually larger than 1 liter, which should provide a sufficient safety margin in practice.

Caution: The above conclusions are based on an ideal situation in which air ventilation is being implemented. For specific cases where air ventilation is not ensured, caution is needed since the clean classes cannot be maintained.

The clean system diagrams shown here are for Class 5 equivalent products. For Class 4 or Class 3 equivalent products, consult us.


Evaluations of Cleanliness

Koganei has therefore specified its in-house measurement methods, to conduct evaluations on the cleanroom rating.

The number of particles of the Air Cylinder Cleanroom Specification is measured as shown in the method below.

1. Measurement conditions

1-1 Test circuit: Figure 1 (no suction), Figure 2 (with suction)



1-2 Operating conditions of tested cylinder

- Operating frequency: 1Hz
- Average speed: 500mm/s [20in./sec.]
- Applied pressure: 0.5MPa [73psi.]
- Suction condition: Microejector ME05, Primary side: 0.5MPa [73psi.] applied, Tube: $\phi 6$ [0.236in.]
- Mounting direction: Vertical
- Chamber volume: 8.3 ℓ [0.293ft.³]

2. Particle counter

- Manufacturer/model: RION/KM20
- Suction flow rate: 28.3 ℓ /min [1ft.³/min.]
- Particle diameter: 0.1 μm , 0.2 μm , 0.3 μm , 0.5 μm , 0.7 μm , 1.0 μm

3. Measurement method


- 3-1 Confirmation of number of particles in the measurement system
Under the conditions in the above 1 and 2, using a particle counter to measure the sample for 9 minutes without operating the measurement sample, and confirmed the measured number of particle is 1 piece or less.
- 3-2 Measurement under operation
Under the conditions in the above 1 and 2, operating the measurement sample for 36 minutes, and measured the total values in the latter half of 18 minutes test.
- 3-3 Reconfirmation
Performed the measurement in 3-1 again, to reconfirm the number of particles in the measurement system.

4. Measurement results

● Cleanroom specification

Jig Cylinder (no suction from dust collection port)


Particle generation over 1 million operations (CS-CDA16 \times 30)



● Cleanroom specification

Slim Cylinder (with suction from dust collection port)

Particle generation over 1 million operations (CS-DA20 \times 100)



For “safety precautions” listed in the Clean System Product Drawings, see the materials below.


- For actuators, see “Safety Precautions” on p. 45 of the Actuators General Catalog .
- For valves, see “Safety Precautions” on p. 31 of the Valves General Catalog.
- For air treatment and auxiliary equipment, see “Safety Precautions” on p.31 of the General Catalog of Air Treatment, Auxiliary, Vacuum.

KOGANEI CLEAN SYSTEM PRECISION REGULATOR

CS-PR200



Symbol




Specifications

Item	Model	PR200
Media		Air
Port size	Rc	1/4
Sensitivity	MPa [psi.]	0.001 [0.15]
Pressure setting range	MPa [psi.]	0.005~0.25 [0.73~36]
Maximum operating pressure	MPa [psi.]	0.73 [106]
Proof pressure	MPa [psi.]	1.03 [149]
Operating temperature range (atmosphere and media)	°C [°F]	5~60 [41~140]
Air consumption ^{Note}	ℓ /min [ft. ³ /min.] (ANR)	5 [0.18]
Lubrication		Not required
Mass	kg [lb.]	0.29 [0.64]
Materials		Aluminum die-casting


Note: Values when secondary air pressure is 0.25MPa [36psi.].

Order Codes




Remark: For details of the **G3** pressure gauge, see **G3-40** of the General Catalog of Air Treatment, Auxiliary, Vacuum.


Inner Construction and Major parts



Flow Rate Characteristics




Pressure Characteristics



1MPa = 145psi., 1 ℓ /min = 0.0353ft³/min.

Dimensions mm [in.]

CS-PR200



Small Precision Pressure Gauge Specifications

Note: The Small Precision Pressure Gauge is not a clean system product.

Item	Model	G3P-40
Media		Air
Operation method		Bourdon tube
Port size		R1/4 (M5×0.8)
Pressure indication range	MPa [psi.]	0~0.3 [0~44]
Maximum operating pressure	MPa [psi.]	0.25 [36]
Operating temperature range	°C [°F]	-5~60 [23~140]
Pressure indication accuracy		F.S.±1% (0.003MPa [±0.44psi.])
Minimum measurement unit		0.005MPa [±0.73psi.]
Guaranteed temperature accuracy range	°C [°F]	25±5 [77±9]
Temperature coefficient		0.05% F.S./°C
Shock resistance	m/s ² {G}	9.8 {1.0} max.
Materials	Body (pressure gauge case)	SPCC
	Case/mounting ring (panel mount assembly)	Plastic (ABS/POM)
Mass	g [oz.]	90 [3.17]



Order Codes of Pressure Gauge Single Unit

G3P - 40 - []


Blank — Without throttle valve
S — With throttle valve^{Note}

Outer diameter
40 — Outer diameter 40mm [1.575in.] (Scale plate)


Small precision pressure gauge
Pressure indication range 0.3MPa [44psi.]

Note: The throttle valve can be ordered separately.

Dimensions of Small Precision Pressure Gauge mm [in.]



Additional parts (To be ordered separately)



Throttle valve